

A2104 STEAM CLEANER HYDROVAP PRO (automatic refilling)



Product group

Steam generators for cleaning and sanitizing purposes

Main features

- ⇒ Fully insulated boiler in stainless steel, with storage capacity of 4.9 liters
- ⇒ Heating resistance not plunged in water thus preventing from any possible contamination due to the presence of limestone
- ⇒ Pressure switch, thermostat and safety valve
- ⇒ Working pressure 6 BAR
- ⇒ Water temperature 155 ° C
- ⇒ Actual volume of water in the boiler 2.0l = long range steam
- ⇒ Time required to reach the temperature = less than 15 min
- ⇒ Handpiece delivering steam only or hydrated steam (steam aggregated to water not picked up from the boiler but heated up when requested).
- ⇒ Fixed jet delivering dry steam through foot-control
- ⇒ Adjustable flows
- ⇒ Using tap water (no need for distilled water)
- ⇒ Automatic loading from the water network
- ⇒ Dual level control: if water is lacking in the external tank a signal will warn, the absence of water inside the boiler will cause the unit to stop heating
- ⇒ Level control with exclusive automatic filling system: interventions are quite brief and frequent thus avoiding the internal temperature to fall down

Boiler capacity

4.9 liters (total), 2.0 liters occupied by water and the remaining space is exploited to create an ideal steam layer

Water temperature

155°C

Working pressure

6 BAR

Power of heating
resistance

1500W

Time required to reach final temperature	Less than 15 min
Filling	Automatic from the water network (direct connection)
Steam output	Fixed jet or through handpiece
Steam flow (handpiece)	Adjustable
Hydrated steam supply	Through handpiece
Hot water flow	Adjustable
Line voltage	230v AC 50/60 Hz
Width	380 mm
Depth	480 mm
Height	420 mm
Net weight	16,0 Kg
Gross weight	19.0 Kg